

# Connecting Link Instructions

## MissingLink



1. Fit chain with the correct length, clean bearing and lubricate



2. Do not forget to lubricate the pin



3. Insert both halves of the MissingLink into the chain ends



4. Press both halves of the MissingLink connector together




5. Lock in place by pulling the chain apart



6. Opening: press both plates together while sliding the chain ends towards each other

## Snap-On



1. Fit chain with the correct length, clean and lubricate bearing and pin



2. Insert pin plate into both chain ends



3. Fit other plate over right pin



4. Bend both ends of the chain slightly towards you and click in the other end



5. Check connectors for correct assembly. Opening: bend chain slightly and pull off the plate

## Spring-Clip



1. Fit chain with the correct length, clean and lubricate bearing and pin



2. Insert pin plate into both chain ends, then fit other plate over both pins



3. Place spring over both pins (note: the closed side of the spring must be in the forward pedalling direction of the chain!)



4. Use pliers to assemble spring

## Correct chain length

Mount on smallest sprocket and smallest ring: the chain should to run as close as possible to, but just free of the derailleur pulley

